

## Sharp XE A 137/147

Schloß auf Z/PGM drehen

Steuer anpassen

#/ST 9 X

1	X	0190000	#/ST
2	X	0070000	#/ST

BAR/TL/NS

---

Steuertexte anpassen

Zahlen immer mit **Doppel Null Taste 00** bestätigen

#/ST 103 X

3	X	085 00 077 00 083 00 065 00 084 00 090 00 032 00 032 00 032 00 049 00 057 00 037 00	#/ST
4	X	085 00 077 00 083 00 065 00 084 00 090 00 032 00 032 00 032 00 032 00 055 00 037 00	#/ST
7	X	077 00 087 00 083 00 084 00 032 00 032 00 032 00 032 00 049 00 057 00 037 00	#/ST
8	X	077 00 087 00 083 00 084 00 032 00 032 00 032 00 032 00 032 00 055 00 037 00	#/ST
48	X	078 00 069 00 084 00 084 00 079 00 032 00 032 00 032 00 032 00 049 00 057 00 037 00	#/ST
49	X	078 00 069 00 084 00 084 00 079 00 032 00 032 00 032 00 032 00 055 00 037 00	#/ST

BAR/TL/NS